

PART NUMBER	OEM	QTY	DESCRIPTION
15306	MAN	6	BACK UP ROLLER
19275	MAN	11	HOLDER FOR PROXI (FESTO) 19275
19276	MAN	11	HOLDER FOR PROXI (FESTO) 19276
19277	MAN	26	HOLDER FOR PROXI (FESTO)
85163	MAN	2	POWER SUPPLY MURR ELEC
126951	MAN	1	SOUNDER L41/L42
151530	MAN	1	RESISTOR,2.5W,0.33 OHM-SIL APP MD
369589	MAN	1	FESTO PRESSURE REGULATOR L41 L42
399054	MAN	1	ANTEK PAN ROLL MOTOR. (USED)
458405	MAN	1	ANTEK MOTOR AND GEARBOX.
513230	MAN	5	SOLENOID PLUG 3 PIN+
1103020806	MAN	8	T/COUPLE MEG/L41/2/HB1 DRYERS 800MM
9000005221	MAN	8	HARTING LEVER FOR PPL ON L41/L42
.86M25SHS/50	MAN	7	SOCKET SHOULDER SCREW M8X25
04.37138-0015	MAN	1	OIL FEED PIPE FOR M.A.N L41/2
06.01283-0807	MAN	4	HEXAGON SCREW OSCILLATING ROLLER
06.02103-0302	MAN	23	ALL CAP SCREW GR 040/117
06.02722-0102 BOLTS	MAN	10	MOVEABLE JAW LOCKING BOLT
06.06140-0105	MAN	8	SPRING LOADED THRUST PIECE
06.06186-0707	MAN	13	BUSH 06.06186-0707
06.08720-0101	MAN	4	PLUG FOR CAM
06.11022-2215	MAN	9	NUT M12 FOR ROLLER ADJUSTERS L41/L42
06.11022-2265	MAN	8	NUT M12 FOR ROLLER ADJUSTERS L41/L42
06.11029-0032	MAN	32	HEXAGON HEAD NUT
06.15114-0218	MAN	20	WASHER
06.15710-0102	MAN	3	WASHER FOR OSCILLATING ROLLER
06.22020-1114	MAN	10	PIN FOR FOR ROLLER SUPPORT L41/42
06.22020-3113	MAN	8	PIN CYLINDRICAL FOR LITHOMAN
06.22120-0906	MAN	3	TENSION SLEEVE
06.29010-0113	MAN	4	SAFTEY RING FOR L41 ROLLER HOUSING
06.29020-0108	MAN	40	CIRCLIP TAPE ASSY L41 L42
06.31490-3600	MAN	3	BEARING FOR OSCILLATING ROLLER
06.31520-0700	MAN	8	BEARING FOR FOLDING ROLLER
06.32669-0017	MAN	2	BEARING FOR OSCILLATING ROLLER
06.33010-0205	MAN	2	BEARING FOR OSCILLATING ROLLER
06.33019-0193	MAN	16	BEARING FOR LITHOMAN 4 NA6509R
06.33019-0213	MAN	1	OSCILLATING BEARING AND SLEEVE L41 L42
06.33700-0419	MAN	1	INNER RING THE OSCILLATING ROLLER
06.37700-0121	MAN	1	END DISK FOR M.A.N L41/2
06.46010-0213	MAN	6	PLATE SPRING 06.46010-0213
06.56930-2107	MAN	3	SEAL RING FOR ROLLER SUPPORT L41/42

07.07179-0031	MAN	2	R46 VERSA TOR4/M/K MAN
07.08050-0176	MAN	1	ANGLED CABLE FOR SENSOR 07.98231-0183
07.20737-03	MAN	1	SPINE SPRAY CONTROL PCB L42
07.91171-0064	MAN	1	SHRINK HOSE
07.91171-0071	MAN	1	SHRUNK FORMPART
07.91468.9222	MAN	3	POSITION RELAY K100-102
07.91468-9030	MAN	1	MOTOR CONTROL ASSEMBLY CARD
07.91468-9041	MAN	2	ENCODER MAIN DRIVE/CHILLS L41 (SEE NOTES
07.91468-9221	MAN	3	MEASURING TRANSFORMER
07.91481-9030	MAN	1	KNIEL 5V PSU MAVO RACK
07.91481-9034	MAN	3	KNIEL 12V PSU, MAVO RACK.
07.91486-9140	MAN	1	ENCODER 24VDC SIKO FOR L41
07.91591-9300	MAN	23	CHIP & PIN MEMORY CARD FOR L32 MAVO
07.91690-9060	MAN	1	TOUCH SCREEN FOR L42
07.92008-0001	MAN	4	PC LAMP MULTI-LED 24-28VDC L41
07.92008-0010	MAN	7	lamp multi led-white
07.93025-0059	MAN	2	ENCODER FOR L42 STEGMAN
07.94012-9010	MAN	20	MAVO CONTACT BLOCK FOR INK KEY L31+2
07.94112-0115	MAN	2	LIGHT ELEMENT
07.94112-0120	MAN	1	CONTACT ELEMENT
07.94112-0121	MAN	9	CONTACT BLOCK
07.94112-0132	MAN	6	PC ELEMENT HOLDER L41
07.94112-0140	MAN	4	PUSH BUTTON FOR MAN L41
07.94112-0190	MAN	3	PC ILLUMINATED PUSH BUTTON L41
07.94112-0202	MAN	4	PC SELECTOR BUTTON L41
07.94511-0090	MAN	2	RELAY PHOENIX
07.94741-0041	MAN	2	PROXIMITY SWITCH
07.94741-0047	MAN	1	PROXI FOR GREASE LUB ON UNITS L41
07.94741-0054	MAN	2	PROXI BAUMER
07.94741-0057	MAN	2	PROXIMITY SWITCH FOR OVER SPEED ON L41
07.94741-0070	MAN	3	PROXIMITY SWITCH FOR M.A.N L41+2
07.94741-0084	MAN	2	PROXI EFECTOR
07.94907-0058	MAN	1	ANTEK MOTOR CONTROLER
07.94907-0092	MAN	2	INVERTER FOR L42
07.94907-0156	MAN	2	INVERTER FOR L42 CHECK NOTES
07.94907-0232	MAN	2	LENZE DRIVE FOR L41 INK FOUNTAIN DRIVE
07.94907-0234	MAN	2	LENZE INVERTER 8200 4KW
07.95103-9150	MAN	1	OPTO COUPLING.
07.96001-0010	MAN	1	D-A TACHO TDP 0,2 LT7.
07.96101-0051	MAN	1	TURNER BAR MOTOR(10MM SHAFT)
07.96101-0052	MAN	1	SERVO MOTOR MOTOR (8MM SHAFT)
07.96303-0135	MAN	1	VIBRATOR ADUSTER MOTOR

07.97551-0021	MAN	6	HEAD STOP BRUSH INDI LAMP
07.97633-0043	MAN	1	POTENTIOMETER FOR L42 1K 5%
07.97633-0049	MAN	1	POTENTIOMETER FOR M.A.N L41+2
07.97633-0069	MAN	2	POTENTIOMETER 1K FOR L41 L42
07.97633-0080	MAN	1	POT
07.97633-0100	MAN	2	STOP BUTTON
07.97633-0101	MAN	1	WIRED POT 1 KOHM
07.97633-0118	MAN	3	POTENTIOMETER FOR M.A.N L41+2
07.97633-0142	MAN	1	2 OWEN POTENTIOMETER. / GR.217/024
07.98231-0098	MAN	1	LIGHT SCANNER WEB BREAK-OBSOLETE-NOTES!!
07.98231-0112	MAN	3	WEB BRAKE DETECTOR LEAD L41 L42
07-94112-0143	MAN	2	ILLUMINATED PUSH BUTTON
110.40.151.01.090	MAN	5	CARBON BRUSH FOR FOLDER ON M.A.N L42
1161/26	MAN	3	6MM SILICONE UNIT DRIVE CHAIN LINK
135-332-013	MAN	1	TECHNOTRANS FOOT COVER
135-432-010	MAN	3	IMPELLER-TECHNOTRANS PUMP(MAN)
135-432-011	MAN	3	SPACER-TECHNO PUMP INTER(MAN PRESS)
14MGT-1190-37	MAN	2	BELT FOR SUPERSTRUCTURE ON M.A.N L41+2
14MGT-1568-20	MAN	3	BELT FOR CHUCK DRIVE ON L41 REELSTAND
14MGT-1750-37 X	MAN	1	BELT FOR M.A.N L41+2 SUPERSTRUCTURE
157-028-125	MAN	4	DEUBLIN ROTERY JOINT FOR M.A.N L4 UNIT
157-028-125168	MAN	2	DEUBLIN JOINT
16.00163-0068	MAN	1	PC CABLE 16.00163-0068 MAN
16.01160-0117	MAN	18	SPRING FOR LEAF SPRING
16.01160-0141	MAN	10	LEAF SPRING 87mm LONG (2 PER SET)
16.03228-4080 X	MAN	1	COUPLIN FOR OSCILLATING ROLLER
16.03232-0169 X	MAN	1	LEVER FOR OSCILLATING ROLLER
16.03293-0063	MAN	2	BOLT FOR OSCILLATING ROLLER
16.03460-4025	MAN	3	PNEUMATIC CYLINDER
16.04031-4008	MAN	7	HOLDER GR 040/066
16.04031-4009	MAN	5	HOLDER GR 040/115
16.04094-4001	MAN	10	SCREW GR 040/116
16.04120-4001	MAN	4	ANGLE FOR ROLLER SUPPORT L41/42
16.04132-0599	MAN	1	LEVER FOR L41 ROLLER HOUSING
16.04132-0601	MAN	1	LEVER FOR L41 ROLLER HOUSING
16.04132-0602	MAN	1	LEVER FOR L41 ROLLER HOUSING
16.04160-0017	MAN	2	CYLINDER FOR ROLLER 150 L41 L42
16.04160-0018	MAN	1	CYLINDER FOR LITHOMAN 4
16.04160-0023	MAN	2	SEAL KIT FOR INKER TRIP PISTON L41 L42
16.04168-0052	MAN	2	SUPPORT SHELL FOR ROLLER SUPPORT L41/42
16.04174-0118	MAN	1	THREADED BAR FOR L41 ROLLER HOUSING
16.04174-0142	MAN	3	ROD FOR ROLLER ADJUSTERS L41/L42

16.04174-0145	MAN	1	ROD FOR ROLLER ADJUSTERS L41/L42
16.04174-0147	MAN	1	ROD FOR ROLLER ADJUSTER L41/L42
16.04174-0148	MAN	4	ROD FOR ROLLER ADJUSTER L41/L42
16.04175-0013	MAN	4	ARTICULATION PIECE FOR ROLLER SUPPORTL41
16.04177-0068	MAN	4	SPINDLE FOR ROLLER ADJUSTERS L41/L42
16.04188-0031	MAN	2	COVER FOR ROLLER SUPPORT L41/42
16.04193-0194	MAN	4	BOLT FOR ROLLER ADJUSTERS L41/L42
16.04193-0195	MAN	5	BOLT FOR ROLLER ADJUSTERS L41/L42
16.04193-0197	MAN	2	BOLT FOR ROLLER ADJUSTERS L41/L42
16.04193-0200	MAN	1	PC BOLT L41/L42
16.04193-0204	MAN	4	BOLT FOR ROLLER ADJUSTERS L41/L42
16.04193-0205	MAN	2	BOLT FOR ROLLER ADJUSTERS L41/L42
16.04193-0210	MAN	2	BOLT FOR MAN
16.04193-0212	MAN	10	BOLT FOR ROLLER ADJUSTERS L41/L42
16.04193-0280	MAN	1	BOLT FOR ROLLER ADJUSTERS L41/L42
16.04193-0282	MAN	5	BOLT FOR ROLLER ADJUSTERS L41/L42
16.05306-0907	MAN	1	INK DUCT FOIL FOR L41 L42
16.05306-4211	MAN	2	INK DUCT FOIL
16.09338-0030	MAN	1	FLANGE FOR DAMPER DRIVE ROLLERL42 / L41
16.09338-0034	MAN	2	FLANGE FOR DAMPER ROLLER L41/L42
16.09360-0034	MAN	1	CYLINDER FOR LITHOMAN 4
16.09360-0053	MAN	4	CYLINDER FOR DAMPER THROW OUT
16.09376-0057	MAN	1	FLANGE FOR DAMPER DRIVE ROLLER L41 L42
16.09389-4006	MAN	1	SLIDE PLATE FOR M.A.N L41/2
16.09960-0011	MAN	14	DAMPER TROFF SEALING STRIP TEFLON
16.11234-0034	MAN	3	GUARD LATCH UNITS
16.12578-0513	MAN	1	GEAR FOR L42 UNIT 41T
16.15501-4102	MAN	2	FORMER NOSE PLATE
16.17360-0042	MAN	1	SLITTER DRIVER MOTOR
16.20432-0392	MAN	5	PIN LEVER (PIN LEVER) / GR.204/055
16.20432-0393	MAN	2	PIN LEVER (2 PIN) / GR.204/057
16.20432-0443	MAN	4	LEVER
16.20440-0336	MAN	22	SEGMENT FOR LITHOMAN "L32&L31
16.20471-0013	MAN	3	TORSION BAR FOR M.A.N L41+2
16.20471-0159	MAN	9	TORSION BAR FOR M.A.N L41+2
16.20471-0170	MAN	2	TORSION BAR SPRING. / GR.204/137
16.20471-0171	MAN	2	TORSION BAR L41+2
16.20471-0173	MAN	5	TORSION BAR FOR MAN L41+2
16.20471-0177	MAN	6	TORSION BAR FOR M.A.N L41+2
16.20473-0015 ASSY	MAN	3	DOUBLE PARRALLEL TUCK CYLINDER ASSEMBLY
16.20473-0017	MAN	25	ROLLER FOR LITHOMAN 4
16.20473-0019	MAN	4	CAM FOLLOWER FOR LITHOMAN 4

16.20473-0020	MAN	5	ROLLER FOR M.A.N L41/2
16.20493-0239	MAN	13	BOLT FOR M.A.N L41+2
16.20493-0242	MAN	1	BOLT FOR FOLDER ON M.A.N L41+2
16.20494-0017	MAN	6	BOLT FOR TORSION BAR L41+2
16.207578-0282	MAN	2	SPUR GEAR FOR M.A.N L41/2
16.20877-0038	MAN	1	SPINDLE FOR L41/2 FOLDER
16.21032-0428	MAN	11	LEVER
16.21093-0250	MAN	2	BOLT FOR FOLDER ON MAN L41+2
16.21432-0090	MAN	3	CAM FOLLOWER ARM
16.21432-0090 ASSY	MAN	2	DOUBLE PARRALLEL GRIP CYLINDER ASSEMBLY
16.21493-0114	MAN	3	CAM FOLLOWER BOLT
16.21506-0004	MAN	1	SHEET METAL PLATE FOR M.A.N L41/2
16.21506-0005	MAN	1	SHEET METAL PLATE FOR M.A.N L41/2
16.21520-0003	MAN	1	ANGLE FOR M.A.M L41/2
16.21526-0001	MAN	6	STUD BOLT FOR M.A.N L41/2
16.21531-0041	MAN	1	HOLDER FOR M.A.N L41/2
16.21760-0023	MAN	4	CYLINDER FOR MAIN NIP ON L41/L42
16.22005-0061	MAN	2	ECCENTRIC HOLD DOWN BRACKETS L41 /L42
16.22010-0427	MAN	2	SLOW DOWN ROLLERS L41 & L42
16.22024-0665	MAN	2	GOLD FINGER
16.22024-0725	MAN	1	A3 PADDLE STRIPPER FINGER
16.22024-0728	MAN	3	DIVERter FINGER FOR M.A.N L41/2
16.22038-0082	MAN	1	SLOW DOWN ROLLER HOUSING L41/L42
16.22060-0055	MAN	2	MOTOR FOR LOWER 1/3 FOLD L42
16.22060-0082	MAN	38	TIGHTENING ROLLER WITHOUT FLANGE
16.22060-0083	MAN	60	PULLEY FOR LITHOMAN 4
16.22060-0086	MAN	4	PULLEYFOR L41 L42 CHECK NOTE
16.22060-0091	MAN	16	VULKOLLAN INSERT
16.22073-0259	MAN	2	PULLEY FOR LITHOMAN 4
16.22077-0207	MAN	1	TAPE ROLLER SHAFT FOR M.A.N L41/2
16.22098-0132	MAN	2	END DISC SPACERS L41 / L42
16.22131-0002	MAN	6	LEVER
16.22132-0003	MAN	3	LEVER. / GR.204/068
16.22132-0003 ASSY	MAN	5	1ST FOLD JAW CYLINDER ASSEMBLY
16.22132-0005	MAN	3	LEVER FOR CAM FOLLOWER L41+2
16.22132-0005 ASSY 2	MAN	5	COLLECT TUCK CYLINDER ASSEMBLY
16.22132-0009	MAN	4	LEVER FOR LITHOMAN 4
16.22132-0010	MAN	1	LEVER. / GR210/208
16.22132-0010 ASSY	MAN	2	2ND FOLD JAW CYLINDER ASSEMBLY
16.22132-005 ASSY 1	MAN	4	COLLECT PIN CYLINDER ASSEMBLY
16.22132-0090	MAN	1	LEVER FOR CAM FOLLOWER ON MAN L41+2
16.22724-6921	MAN	1	GUIDE FINGER

16.22724-6922	MAN	1	GUIDE FINGER
16.22724-6923	MAN	1	GUIDE FINGER
16.22724-6924	MAN	1	GUIDE FINGER
16.22724-6925	MAN	1	GUIDE FINGER
16.22724-6926	MAN	1	GUIDE FINGER
16.23060-0012	MAN	83	PULLEY FOR LITHOMAN 4
16.23060-0022	MAN	8	PULLEY FOR LITHOMAN 4
16.23076-0346	MAN	1	SHAFT FOR TAPE ROLLER ASSY
16.23077-0103	MAN	1	SHAFT FOR TAPE PULLEY L41
16.24260-0192	MAN	1	OIL FLOW PRESSURE SWITCH L41/L42
16.24260-0203	MAN	2	SAS400 OIL FLOW PRESSURE SWITCH L41/L42
16.24260-0206	MAN	2	SAS1250 OIL FLOW PRESSURE SWITCH
16.24260-0208	MAN	3	SAS2000 OIL FLOW PRESSURE SWITCH L41/L42
16.24260-0210	MAN	1	SAS3150 FLOW CONTROL VALVE / GR.242/206
16.24260-0212	MAN	2	SAS5000 OIL FLOW PRESSURE SWITCH L41/L42
16.25060-0361	MAN	1	MOTOR FOR CHILL MAIN DRIVE L41/L42
16.30235-0010	MAN	1	COUPLING FOR M.A.N L41/2
16.31206-0385	MAN	1	ROCKER PLATE L41
16.31206-0386	MAN	1	ROCKER PLATE L41
16.31273-0006	MAN	5	PULLEY
16.31273-0007	MAN	2	ROLLER FOR LITHOMAN 4
16.31273-0017	MAN	9	ROLLER FOR M.A.N L4
16.31273-0018	MAN	3	ROLLER FOR LITHOMAN 4
16.31277-0004	MAN	7	SCREWED ROD
16.31293-0104	MAN	6	ROLLER SUPPORT
16.31299-0068	MAN	43	BEARING SPACER
16.31299-0070	MAN	5	DISTANCE RING 16.31299-0070
16.31299-0073	MAN	28	DISTANCE RING
16.31410-0624	MAN	2	FOLDING ROLLER FOR L41+2
16.31431-0032	MAN	1	CLAMPING PIECE
16.33831-0034	MAN	1	GUIDE FINGER HOLDER
16.52073-0005	MAN	1	ROLLER FOR M.A.N
16.52508-7002	MAN	22	SINGLE ACTING CYLINDER L41 & L42
16.52560-4011	MAN	2	PC SEALING SET FOR PNEUMATIC CYLINDER
16.52660-0214	MAN	50	ADJUSTING KNOBS
16.63360-0212	MAN	1	BRAKE CALIPER
16.63398-0065	MAN	1	BRAKE DISC
16.71560-0203	MAN	1	INFEED UNIT MOTOR L41
16.86132-0030	MAN	1	MODULE FOR L42 CONTROL UNIT 1
16.86923-0007	MAN	4	MODULE
16.86925-0016	MAN	4	MODULE
16.86925-0023	MAN	1	MODULE

16.86926-0008	MAN	2	MODULE
16.86929-0006	MAN	1	INK DUCT INTERFACE / TYPE 1.IPS.IBI-1
16.86953-0008	MAN	1	MODULE
16.86958-0013	MAN	1	MOTOR CONTROL PCB
16.86958-0017	MAN	1	MODULE
16.86958-0029	MAN	1	MOTOR CONTROL MODULE
16.86959-0001	MAN	2	BUS ADAPTOR
16.87132-0018	MAN	1	ARCNET CARD FOR L42
16.97008-0728 X	MAN	3	CYLINDER DOUBLE ACTING - NORGREN
16.97055-0086	MAN	3	TIMING BELT FOR M.A.N L4
16.97055-0226 X	MAN	1	TIMING BELT FOR M.A.N L4
16.97055-0257	MAN	3	TIMING BELT FOR MAN L4
16.97055-0469	MAN	2	TIMING BELT FOR M.A.N L4
16.97055-0490	MAN	1	TIMING BELT FOR M.A.N L4
16.97055-0887	MAN	2	TIMING BELT FOR M.A.N L4
16.97055-1002	MAN	2	BELT FOR INFEED MOTOR L41
16.97055-1097	MAN	2	TIMING BELT FOR M.A.N L4
16.97055-1367	MAN	3	TIMING BELT FOR M.A.N L4
16.97055-1414	MAN	3	TIMING BELT FOR M.A.N L4
16.97055-1425	MAN	6	TIMING BELT FOR M.A.N L4
16.97055-1429	MAN	3	TIMING BELT FOR M.A.N L4
16.97055-1430	MAN	1	TIMING BELT FOR M.A.N L4
16.97055-1440	MAN	2	TIMING BELT FOR M.A.N L4
16.97055-1443	MAN	6	TIMING BELT FOR M.A.N L4
16.97055-1448	MAN	2	TIMING BELT FOR M.A.N L4
16.97055-1457	MAN	2	TIMING BELT FOR M.A.N L4
16.97055-1493	MAN	3	TIMING BELT FOR M.A.N L4
16.97055-1574	MAN	3	TIMING BELT FOR M.A.N L4 DOUBLE SIDE
16.97055-1597	MAN	1	TIMING BELT DOUBLE TOOTH FOR M.A.N L4
16.97055-1605	MAN	1	TIMING BELT FOR M.A.N L4
16.97055-1689	MAN	2	TIMING BELT FOR M.A.N L4
16.97055-1690	MAN	2	TIMING BELT DOUBLE TOOTH FOR M.A.N L4
16.97055-1790	MAN	1	DOUBLE TOOTH TIMING BELT FOR M.A.N L4
16.97055-1990	MAN	3	BELT FOR L41 L42
16.97055-1996	MAN	1	BELT FOR MAN L41 DOUBLE SIDED
16.97060-0404	MAN	2	CLOSING PIN FOR GUARDS
16.97060-2018	MAN	2	FILTER ELEMENT FOR UNIT
16.97060-2101	MAN	2	FILTER ELEMENT FOR FOLDER
16.97060-2788	MAN	8	SOLENOID VALVE FOR M.A.N L4
16.97060-2800	MAN	2	FESTO MODULE FOR MAN
16.97060-3319	MAN	3	READ SWITCH FOR L41 L42 **CHECK NOTES**
16.97060-3378	MAN	1	PC BUTTON L41/L42

16.97060-4120	MAN	4	BOLT
16.97060-5367	MAN	1	REFLECTING FOIL
16.97061-1856	MAN	3	SEAL KIT FOR DAMPER CYLINDER
16.97061-1859	MAN	1	SEAL KIT FOR CYLINDER 16.03460-0039
16.97061-1863	MAN	2	SEAL KIT FOR CYLINDER 16.09360-0053
16.97061-1867	MAN	5	SEAL KIT FOR PISTON NIPS
16.97061-4102	MAN	1	SHAFT FOR INKER CYLINDER 16.04160-0018
16.97085-0074	MAN	3	GREASE NIPPLE FOR FOLDER JAW COLLECT DP
16.97089-0014	MAN	40	CASE FOR LITHOMAN 4
16.97089-0037	MAN	3	DAMPER TRAY DROP IN LATCHING PIN
1LG6207-4MA61	MAN	1	SIEMENS MOTOR 32 FOR MEG
1PH7186-9EL330BK5-Z	MAN	1	SIEMENS UNIT MAIN DRIVE MOTOR
25.60002-7369	MAN	1	DIVERTED FINGER SETTING GAUGES
255-000-003	MAN	2	DEUBLIN FOR L41
257-000-284	MAN	3	DEUBLIN FOR L41
30/62RS	MAN	15	BEARING FOR PATH ROLLER IN FOLDER L41
399-3084	MAN	1	STOP BUTTON
3SE32001F	MAN	3	UNIT GUARD SWITCH SIEMENS **CHECK NOTES*
45060043 PES80A	MAN	1	CYLINDER L42 DRYER
5.021.02.007	MAN	2	IDLE PULLEY L41 PALLETISER
5.021.02.016	MAN	1	TIMING PULLEY L41 PALLETISER
525-414-054	MAN	2	DEUBLIN UNION FOR MAN CHILLS
527-130-054	MAN	2	DEUBLIN UNION FOR MAN
6EP1437-2BA20	MAN	1	SIEMENS POWER SUPPLY
6ES7307-1EA01-0AA0	MAN	2	SIEMENS POWER SUPPLY 24VDC 5A
6SE7031-0TE50-1AA1-Z	MAN	1	SIEMENS SIMOVERT INFEED DRIVE L41
70186-00	MAN	3	TURBO VALVE FOR L41 L42 BLANKET WASH
80XL037	MAN	2	GRAFIMONITOR HEAD DRIVE TIMING BELT L41
830980DG	MAN	2	SPLINDLER SHAFT-MAN R/STND(APPX 325 / MM
90245OED	MAN	9	WEB UP BAR LINK(MAN REELSTAND)
9-3313M-322	MAN	2	SOLENOID 110/50
ADVULQ-16-10-P-A-S2	MAN	3	FESTO CYLINDER FOR PPL UNIT
ATV66D79N4	MAN	1	ALTIVAR TELEMEC DRIVE 66 FOR L42 DRYER
AZM170-02ZRK-2405	MAN	7	INTERLOCK FOR M.A.N L41+2 SCHMERSAL
C6045D 1027	MAN	2	HONEYWELL PRESSURE SWITCH 15-150 BAR
CC6,621 CP GRB276020	MAN	16	FERRAZ FUSE FOR L42 660V DC 20A
CJM-5/2-1/2-FH 6228	MAN	1	VALVE FOR MAIN CYLINDER TRIP L41 L42
E82ZAFSC	MAN	1	LENZE DRIVE I/O MODULE L41
ESMD152X2SFA	MAN	1	LENZE INVERTER
EVF8216-E	MAN	1	INVERTER 5.5KW
E-VKR50-MSG	MAN	2	COUPLING SPIDER OIL PUMP MOTOR
EWN8399501427000	MAN	4	ENCODER CABLE FOR CHILLS ENCODER.



FF4-4DAH	MAN	2	PRESSURE SWITCH/TIVAL
FOLDER PLATE	MAN	1	FOLDER ROLLER SIDE PLATES
FX2N-4AD	MAN	2	mitsubishi PROGRAMMABLE CONTROLLER DC24V
FXON-60MR-DS	MAN	1	mitsubishi PROGRAMMABLE CONTROLLER
GS-15-80-ETET-V-400N	MAN	6	GAS STRUT
HTD1568X14MX40MM	MAN	2	TIMING BELT
HTD1750X14MX40MM	MAN	2	TIMING BELT
HTD1778X14MX55DD	MAN	1	SUPERSTRUCTURE FOLDER BELT L41
HTD1890X14MX40BELT	MAN	2	HTD1890X14MX40 BELT FOR MAN
HTD2100X14MX40BELT	MAN	1	HTD2100X14MX40BELT FOR MAN
HTD2310X14MX40MM	MAN	1	BELT FOR SUPERSTRUCTURE
IGG51360GG496VV1Z	MAN	1	SIEMENS INFEEED MOTOR FOR L42
IPS.CNT-1	MAN	1	MODULE 16.86925-0008
IWRM18U9501	MAN	1	PROXIMITY SWITCH FOR M.A.N L41+2 BAUMER
JMT2H-5/2-4.0	MAN	12	FESTO AIR VALVE 159453 (FESTO CODE)
KF-11040	MAN	3	ANCHOR BRACKET FOR KNIFE ON L41+2
L180B48-ZA30A	MAN	2	WATER FLOW VALVE FOR L41 CHILLS- MAN
TAPE ASSY	MAN	1	TAPE ROLLER ASSY FOR FOLER
M10 X 25 CAP SCREW	MAN	62	M10 X 25 SHOULDER CAP SCREW
M3AA090-LB4	MAN	2	ABB MOTOR FOR L41/L42 OIL PUMP 1.1KW3PH
ML30-106	MAN	1	PULS POWER SUPPLY
MT2H-5/3E-4,0-S-VI B	MAN	4	FESTO AIR VALVE
MT2H-5/3G-4,0SVIB	MAN	9	SOLOIND VALVE FOR M.A.N L4
NA4907	MAN	1	NEEDLE BEARING L41/L42
NZMN2-A160	MAN	1	RECIRC MOTOR CIRCUIT BREAKER L41/L42
OBF500	MAN	2	PLATE BENDER SENSOR IFM L41 L42
P054072	MAN	4	BRUSH HOLDER ASSEMBLY
R190015220	MAN	16	BEARING FOR MAN L41 REELSTAND REXROTH
R1N	MAN	6	PULLEY FOR L41 L42 FOLDER 30MM
R5N	MAN	11	PULLEY FOR L41 L42 FOLDER
RED TAG 0036	MAN	1	ROLLER FOR L41/2 FOLDER
RED TAG 0038	MAN	2	CYLINDER FOR MAN L41/2
RED TAG 0040	MAN	1	CYLINDER FOR MAN L41/2
RED TAG 0041	MAN	1	REGULATOR FOR L41/2 FOLDER
RED TAG 0042	MAN	1	FESTO CONTROL UNIT ASSY
RED TAG 0057	MAN	2	CHUCK ASSEMBLY
RED TAG 0106	MAN	4	EML WEBBER LINER
RM/8025/N2/80	MAN	26	NORGREN AIR CYLINDER L42 FOLDER
RNA4908	MAN	7	BEARING FOR 123 ROLLER
SHIM	MAN	1	BRASS SHIM FOR M.A.N INK DUCT
SMT-8-PS-S-LED-24-B	MAN	2	FESTO FOLDER REED SWITCH MAN L41 L42
SPA2360	MAN	12	BELT FOR M.A.N GOOD YEAR ONLY



SPB1700	MAN	20	DRYER BELT FOR M.A.N
SPB1800	MAN	9	DRYER BELT FOR M.A.N
SS-600ES	MAN	1	POWER SUPPLY PECOM COMPUTER
VCMF0000	MAN	8	CONVERTER MODULE
VCMH0000	MAN	7	CONVERTER MODULE
XCMD3902L2	MAN	4	SENSOR/TELEMEC
XPA1120	MAN	6	BELT FOR L41 DRYER GOODYEAR
XPA2360	MAN	12	BELT FOR MAN GOOD YEAR ONLY
ZB5AW313	MAN	2	PROTECTED LED